



01C.61


# ENGLISH

### 01C.61 EXTERNAL TEMPERATURE SENSOR

## **TECHNICAL DATA**

Sensing range (-20...+90)°C Resolution: - 0.1°C (-9.9...+90)°C - 1°C (-10...-20)°C Maximum cable length 20 m Degree of protection IP54

### WIRING DIAGRAM



Link terminals A and B of the sensor to terminals A and B of the chronothermostat (maximum cable length: 20 m)

# NOTE

- For connection, use a shielded cable (eg alarm system cable)
- In the case where the sensor cable must pass in close proximity to other conductors particularly those at 230 VAC, use a shielded cable of group 3 with reinforced insulation
- Exercise caution and use a cable appropriate to the temperature being detected
- Connect the sensor, and the temperature will be displayed after 1 minute
- The sensor temperature is read every minute

### PROGRAMMING

When used with the 1C.61 see the thermostat instruction manual, paragraph 9 of the Advanced Menu.

#### IB01C61 - 04/21 Finder S.p.A. con unico socio 10040 ALMESE (TO) - ITALY

# finder